



RIM DRIVE TECHNOLOGY

RD SKS Bried Installation and Operator Manual

Ref: RD-SKS-IOM-06

Contents

Overview	2
System components	2
System Block Diagram	3
Mechanical Installation	3
RD SKS Control Helm Joystick Installation:	3
System Status LED Panel Installation:	4
RD SKS Control Box Installation:	4
Electrical Installation	6
RD SKS Control Box Port Description	7
Data for positioning System:	9
Connecting to thrusters:.....	9
Operator Manual.....	10
System Operation Steps:	13
LED Combinations and system states:	14
Error Codes:	16
System Configuration:.....	17
Connecting PC to control box:.....	18
Start the System Tuning and Configuration Tool:	18
Enter Vessel Configuration Parameters:	18
Controller Tuning:.....	19
Heading Controller:.....	20
Position Controller:	21
Tuning Process:.....	21
Diagnostics:	22
Notes:.....	22

Overview

Rim Drive's SKS (Station Keeping System) compliments Rim Drive's drive by wire controls by enabling the vessel to perform automated behaviors. The SKS primarily consists of a control joystick and a control box. Furthermore, it allows users to add multiple control helms and directly interfaces with advanced remote monitoring solutions.

System components

The following components are included in each RD-SKS kit.

Component	Photo
RD SKS Control Box	
SKS Joystick	
System Status LED Panel	
Network & Setup Cable	M12, X-Code, 8 pin Male to RJ45
Main Helm Station Cable	M12, A-Code, 8 pin Female to free end
SKS Joystick Cable	M12, A-Code, 5 pin female to 5 pin female
Power Cable	M12, A-Code, 8 pin female to free end
RD Network Cable	M12, A-Code, 5 pin female to free end

System Block Diagram



Figure 1: System Block Diagram

Mechanical Installation

RD SKS Control Helm Joystick Installation:

Position and install the *RD SKS Control Helm Joystick* on the dashboard in a location that provides unobstructed and ergonomically convenient access. Where practicable, mount the joystick on a horizontal surface and in a zone shielded from direct water spray to ensure optimal performance and longevity.

Use the following dimensions for the cutout.




Figure 2: Joystick cutout

System Status LED Panel Installation:

Install the System Status LED Panel on the dashboard in a location that provides clear visibility. Keep away from direct sunlight and water spray when possible. Use the following dimensions to create an appropriate template for a cutout.




Figure 3: System Status LED Panel

RD SKS Control Box Installation:

The *RD SKS Control Box* may be installed in any orientation. It should be positioned to allow for straightforward cable routing and placed as near as possible to the *RD SKS Control Helm Joystick*. Although the Control Box is rated IP67, installing it in a dry area is recommended to enhance its service life. Exposure to direct sunlight must be avoided. Use the following

dimensions to plan installation of the control box.




Figure 4: RD SKS Control Box dimensions

Electrical Installation

Read through this section before wiring the system according to the wiring diagram.





Figure 5: Wiring Diagram

RD SKS Control Box Port Description



I/O Label	Type <i>Connector gender specified applies to the controller panel connector, not the mating cable</i>	Function
ETH1	M12, A-Code, 8 pin female	Setup port to configuration laptop
ETH2	M12, A-Code, 8 pin female	Connectivity to 4G router
PWR	M12, A-Code, 8 pin male	Power Cable and connection to <i>System Status LED Panel</i>
S1	M12, A-Code, 8 pin female	4 channel analog signals to read commands from the <i>Main Control Helm</i>
S2	M12, A-Code, 5 pin male	RS-232 Port for future integrations if needed
R1	M12, A-Code, 5 pin male	RS-485 Connection to <i>RD SKS Control Helm Joystick</i>
CB1	M12, A-Code, 5 pin male	CAN Bus port for NMEA 2000 connection
CB2	M12, A-Code, 5 pin male	CAN Bus port for CAN Open Port

Power Port: Powers the *RD SKS Control Box*. The *RD SKS Control Box* can take a wide input of 10-30 VDC. Recommended fuse size is 2A.




Figure 6: Pin-outs of M12 8 Pin Male

Table 1: Power Cable Pin outs

Pin Number	Function	Cable Color Code
1	Power In – V+ [9-36VDC]	
2	Power In – V+ [9-36VDC]	
3	Panel LED 1 GREEN	
4	Panel LED 2 GREEN	
5	Panel LED 1 GND	
6	Panel LED 2 RED	
7	Panel LED 2 GND	
8	Panel LED 1 RED	

S1 Port: The S1 port is used to connect the *Main Control Helm* to the *RD SKS Control Box*.




Figure 7: Pin-outs of M12 8 Pin Female

Table 2: S1 Port Main Helm Station Cable Pin-outs

Pin Number	Function	Cable Color Code
1	Power Out – V+ - 5VDC	
2	Power Out – GND	
3	Axis 1	
4	Axis 2	
5	Axis 3	
6	Power Out – GND	
7	Power Out – GND	
8	Power Out – V+ - 5VDC	

Data for positioning System:

The RD SKS can receive position and heading data through two sources. Make sure that you only connect one of them to system.

Source one is via its CB1 port connected to a NMEA 2000 network. The system requires at least 10Hz refresh rate for position and heading to operate correctly.

Source two is via it ethernet connection. Send NMEA 0183 string to the UDP sever with the following address 192.168.10.10 : 5111. When using the second source ensure that all the following strings are sent to the SKS system:

- GGA
- VTG
- HDT

Connecting to thrusters:

When using the SKS system with Rim Drive thrusters, connect the RIM Drive thrusters CAN Bus to the CB2 port. Ensure that the thruster controllers are setup to accept messages over CAN Bus.

Table 3: CB2 Pinouts



Pin Number	Function	Cable Color Code
1	GND	
2	PWR	
3	GND	
4	CAN H	
5	CAN L	


When using third party thrusters and controllers, refer to the instructions in “RDSKS_Interface_Protocol v0.3” to interface with the RD SKS system.


Operator Manual

The system state defined by a) the helm in control and b) the systems operational mode. The system has four operational modes, namely, *Hold*, *Thrust Vectoring*, *Station Keeping* and *Manual*.

Operational Mode	System Behavior
Hold	The SKS is in safety mode and does respond to any joystick command
Thrust Vectoring	The SKS controller converts helm axis commands to thruster combinations which results in a combination of the following forms of motion. Sway Yaw Surge









Station Keeping

The SKS controller tries to maintain the position and heading of the vessel through feedback from


Change set point along
Port-Stbd Axis



Change heading set point



Change set point
along the Fwd-Aft
axis



Manual




The SKS controller maps every axis of the active helm to a direct command on one of the thrusters.

Consider a vessel with two fixed pods and a bow thruster

Adds a differential thrust to port and stbd pods.
Increases thrust on port pod and decreases thrust on stbd pod.

Activates bow thruster

Activates both pods in the forward direction



System Operation Steps:



Figure 8: Joystick Buttons

The system starts in manual mode with the *Main Control Helm* in command. The *Main Control Helm* cannot engage in any mode other than *Manual Mode*.

To take command at the *RD SKS Control Joystick* the user has to press on the *Take Command* button. When pressed the *Take Command* LED on the *RD SKS Control Joystick* starts blinking and then goes solid once a successful transfer of command is completed. The *RD SKS Control Joystick* starts in *Manual Mode* when it takes control.

Note: Transfer of command cannot be completed if the joystick is not in a neutral position

To engage station keeping mode at the *RD SKS Control Helm Joystick* press button A. The A LED goes solid when station keeping mode is engaged.

To engage *Thrust Vectoring Mode* at the *RD SKS Control Helm Joystick* press C. The C LED goes solid when *Thrust Vectoring Mode* is engaged.

To go back to manual mode press BOOST. Both LEDs A and C go solid when the *Manual Mode* is engaged.


To release command back to the *Main Control Helm* press the *Take Command* button. Once command is given to the *Main Control Helm* the *Take Command* button turns off.

LED Combinations and system states:

Helm in command	Operation Mode	RD SKS Control Helm Joystick LEDs	System Status LED Panel
Main Control Helm	Manual		
		All LEDs off	L1 and L2 Solid Green
RD SKS Control Helm Joystick	Manual		
		LEDs A, C and TAKE COMMAND are ON	L1 Solid Green L2 Flashing Green
RD SKS Control Helm Joystick	Thrust Vectoring		
		LEDs C and TAKE COMMAND are ON	L1 Solid Green L2 Flashing Green

*RD SKS
Control
Helm
Joystick*





Station
Keeping



LEDs A and *TAKE COMMAND* are ON

L1 Solid Green L2
Flashing Green

Error Codes:

Error	LED 1	LED 2	Illustration
Unreliable or loss of Heading and/or GPS data	Solid Green	Alternating Red / Green	
Loss of communication with thrusters	Solid Red	Solid Red	
Incorrect GPS or Heading data rate	Solid Green	Flashing Red	
Loss of communication to main helm	Solid Red	Flashing Red	
Loss of communication to joystick helm	Flashing Red	Flashing Red	
Loss of power or loss of connection between Status LED panel and Control Box	Off	Off	

System Configuration:

In order to configure the station keeping system, make sure that you have the following data readily available before starting the configuration of the system.

- Number of thrusters
- Relative location of thrusters
- Types and models of thrusters used

⚠ Warning: Contact manufacturer for a remote tuning and system configuration session.

The system currently supports the following thruster configuration. Please thruster configurations that are not listed here kindly contact manufacturer.

- 0: Single steerable thruster with bow thruster
- 1: Single steerable thruster
- 2: Twin fixed thrusters with bow thruster




Figure 9: Configuration "0" Geometric Parameters




Figure 10: Configuration "1" Geometric Parameters




Figure 11: Configuration “2” Geometric Parameters

Connecting PC to control box:

- 1- Using the provided ETH cable connect the PC to port ETH1 or ETH2.
- 2- Change your PC's IP Address to “192.168.10.20”.
- 3- Ping the controllers to ensure that the control box is operational. The controller has two IP addresses, namely, “192.168.10.10” & “192.168.10.11”.

Start the System Tuning and Configuration Tool:

- 1- Install the configuration tool from the provided link
- 2- Start the configuration tool
- 3- The tool shall connect automatically and read current parameters. Given the control box is powered and connected.

Enter Vessel Configuration Parameters:

⚠ Warning: Do not arm the thrusters prior to this step

RIM DRIVE TECHNOLOGY

Connected

Vessel Configuration 2

L 3.0

LA (m) 0.5

LB (m) 1.5

W (m) 1.0

Steer Limit +/- (Deg) 1.0

BOW THR PWR (%) 50.0

Confirm Vessel Configuration

Figure 12: Vessel Configuration View

- 1- Enter the configuration of the vessel parameters and values. All geometric parameters are as explained in Figure 9, Figure 10 and Figure 11.
- 2- Click on “Confirm Vessel Configuration”
- 3- Test the system in Thrust Vectoring Mode to ensure correct configuration

Notes:


- BOW THR PWR is an estimate of the bow thruster power as a percentage of the main thrusters.
- Steer Limit is the steerable thrusters limit in one direction. For example, if your thrusters go steer 45 degrees to port and 45 degrees to starboard (90 degrees of total travel). Enter Steer Limit as 45.

Controller Tuning:

⚠ Warning:

- **Confirm manual control first: Do not begin the tuning process until basic manual mode has been tested and verified to function correctly.**
- **Choose a safe location: Perform tuning only in open, unobstructed areas. Avoid busy waterways or locations with heavy traffic.**

- **Maintain safety readiness:** Ensure that system disarmament is accessible at all times throughout the tuning process.



Heading Controller:

The Heading controller manages how assertively the controller adjusts thrusters commands to adjust the vessel's current heading

- **Heading_P – Proportional Gain**
Controls the immediate thrusters response to heading error.
Higher values result in more aggressive responses.
- **Heading_I – Integral Gain**
Corrects steady-state error over time.
Typically left unchanged; modify only if persistent heading offset is observed.
- **Heading_D – Derivative Gain**
Dampens rapid changes in heading to reduce overshooting.
Higher values lead to smoother, more stable responses.

Position Controller:

The position controller manages the thruster response towards differences between the current position and desired position of the vessel. The system has two position controllers, namely, the x position and y position controllers. The x position controller affects the vessel response along its bow-stern axis and the y position controller affects the vessel response along its port-starboard axis.

- PXY_P – Proportional Gain

Controls the immediate thrusters response to position error.
Higher values result in more aggressive responses.

- PXY_I – Integral Gain


Corrects steady-state error over time.
Typically left unchanged; modify only if persistent positioning offset is observed.

- PXY_D – Derivative Gain

Dampens rapid changes in heading to reduce overshooting.
Higher values lead to smoother, more stable responses.

Tuning Process:

- 1- Start the PlotJuggler Application to monitor vessel responses and controller commands



- 2- Enter the following configuration for the UDP Server:
 - a. Port: 4287
 - b. Protocol: JSON
- 3- Load the provided system layout to view heading and position errors
- 4- Engage Station Keeping mode on using the *RD SKS Control Helm Joystick*.
- 5- Modify the control parameters gradually and observe system response.

- 6- Start by tuning the heading controller then transition to position controllers.
- 7- Click on “Write Configuration” once tuning is complete.

Diagnostics:

The current version shows limited diagnostics and those can be accessed using a web browser. Enter the IP address of the controller “192.168.10.11”.

Notes:

Access to functions which allow for reversing thrusters and steering directions are currently restricted. Those functions which would be required for a complete system setup are only accessible to certified installers.



RIM DRIVE TECHNOLOGY

Uncompromised Electric Motors

www.rimdrivetechology.nl

+31 (0) 85 482 48 55

info@rimdrivetechology.nl